




Fig. 1











FIG. 3






FIG. 5




FIG. 6




Fig. 7

135

SAMPLE INPUT BALLOT

Sample Instructions:

1. You have **NOT** voted until you receive your Ballot Receipt and have placed your Machine Printed Ballot in the lock box.
2. You **MUST** check one and **only one** box for **each**

ballot item as follows:



3. If you do not wish to vote for a ballot item, you must check the "No Vote" box.
4. You may erase any box checked in error.
5. You may get a new ballot.
6. You may ask elections officials for help.
7. You will have a chance to correct any errors *after* the computer "reads" your Ballot and prints your Ballot Receipt.

Item 1. President of the United States

Candidate 1.	<u>Candidate A</u>	—
Candidate 2.	<u>Candidate B</u>	—
Candidate 3.	<u>Candidate C</u>	—
Right-In	4. Print Name _____	
No Vote	5. <u>I do not wish to vote on Item 1</u>	

Fig. 8

145

SAMPLE VOTER RECEIPT

Sample Instructions:

- 1. This receipt is your guarantee that your vote will count exactly as you marked your ballot.**
- 2. Your vote is secret.**
- 3. You can check your vote in one week using the following secret password:
xxx xxx xxx xxx xxx xxx x**
- 4. You may secretly check your vote at your nearest election office or on the Internet at: XYZ
County.state.elections.gov.**
- 5. Immediately report any differences between this ballot receipt and how your vote is recorded by the election department to the state attorney's office at
xxx-xxx-xxxx**
- 6. Selling your vote is a crime punishable by
imprisonment**

Item 1. President of the United States – Candidate B

Fig. 9

155



SAMPLE OFFICIAL BALLOT

Sample Instructions:

- 1. Review to make sure this ballot is exactly how you want to vote.**
 - 2. Return to the ballot counting station if there is an error.**
 - 3. Place your Official Ballot in the lock box if it is correct.**
-

Item 1. President of the United States – Candidate B

Fig. 10

165



ERROR REPORT

Sample Instructions:

1. Your vote **WILL NOT COUNT** until the following errors have been corrected.
2. You must erase and/or remark your ballot.
3. Take your corrected ballot back to the ballot counting station.

Item #1 has more than one box checked. Erase all check marks but one.

Item #2 has no box checked. Check one box only. If you do not wish to vote on that item, check the "No Vote" box.

Fig. 11